

ART. 899052, 899054, 899056, 89906, 8990605, 89907, 89908, 8990805, 89911, 8990601, 8990606



NÁVOD PRO INSTALACI BLATNÍKŮ FORCE ALUFLEX

1. Přední blatník musí být instalován min. 15 mm či dále od pláště kola. Vzdálenost min. 15 mm musí být za každých okolností dodržena. V případě nedodržení zvyšujete riziko nehody.
2. Blatníky musí být instalovány bez natahování, ohýbání nebo úpravy poloměru profilu.
3. Tvar vzpěr a úhel mezi rameny vzpěr nesmí být změněn. Změna úhlu může mít za následek nesprávnou funkci blatníků.
4. Blatníky vybavené posuvnými (stavitelnými) vzpěrami jsou dodávány s plastovými koncovkami, které jsou navrženy tak, aby zakrývaly ostré konce vzpěr. Pokud nejsou nainstalovány koncovky, může dojít k poranění kůže nebo jiným nehodám. Použití těchto koncovek zvyšuje bezpečnost uživatele.
5. Jelikož ne všechny rámy kol mají shodně připraveny úchyty pro upevnění vzpěr, je v některých případech nutno upravit délku vzpěry jejím zkrácením tak, aby blatník byl ve správné pozici vzhledem k plášti kola.
6. Výrobce/distributor doporučuje instalaci blatníků na kolo přenechat specializovanému servisu.



MANUAL FOR FORCE ALUFLEX MUDGUARDS

1. The front mudguard must be installed min. 15 mm or further from the tyre. The distance of at least 15 mm must be observed in all circumstances, otherwise you increase the risk of an accident.
2. The mudguards must be installed without stretching or bending, any undesirable changes to the profile radius must be avoided.
3. The shape of the struts used on the mudguards must not be changed, in particular the angle between the arms of the struts. By change this angle may result in malfunction.
4. Mudguards equipped with sliding (adjustable) struts are supplied with plastic ends designed to cover the sharp ends of the struts. If those plastic ends are not installed, skin injuries or other accidents may occur. The use of those plastic ends increases the safety of the user/rider.
5. As not all bike frames have exactly the same position of threads for struts mounting, in some cases it is necessary to adjust the length of the struts by shortening it so that the mudguard is in the correct position to wheel tyre.
6. Producer/distributor recommends installation of mudguards on the bike in a specialized service.

